

# 6'X3' Garden in a Box Trellis with Lid Kit

## Made with North American Western Red Cedar


www.CedarShedAndGardenKits.com


info@CedarShedAndGardenKits.com

Free Delivery from the Factory to your Home, Ranch or Business.

Thanks for your interest in the 6x3 Garden in a Box.

Safety Points and Other Considerations Please follow this instruction manual when assembling your Raised Garden Bed and retain the manual for future maintenance purposes.





### Trellis/Lid Dimensions:

A: Width = 72"

B: Height with Lid Closed = 35"

C: Height to top of Trellis = 71"

**Estimated Assembly Time for the** Lid/Trellis Option = 1/2 Hour.

In the event of missing or broken pieces, please call the Customer Support Line within 30 days of the delivery of your kit. You'll find the number in your Assembly Manual that comes with the kit. It is our commitment to you to deliver replacement parts, free of charge, within 10 business days of your notification. Replacement parts will not be provided free of charge after the 30 day grace period.

## **Exploded View and Parts List for Trellis/Lid Kit**


#### **Parts List**

**Part A** 2 - Trellis/Lid Panels 36" wide x 37 1/2" high

Part B 4 - Plastic Hinges

<u>Part C</u> 2 - Trellis/Lid Arms 3/4" t x 1 1/2" w x 26" l

<u>Part D</u> 1 - Rear Trellis Cleat 3/4" t x 2 1/2" w x 33" h
















**1.** Orientate **Trellis/Lid Panels - Part A** (screen down) as illustrated below on flat level ground. Align so vertical framings are tight together. Use wood clamp to hold framings together.




Important - If Raised Bed is not square and level, Trellis/Lid may not fit and align correctly. Before positioning, measure and align bed framing as square as possible.




**4.** With Trellis/Lid evenly positioned on raised bed framing, locate **4 Black Plastic Hinges - Part B** and **24 - 3/4" Black Screws.** Align 1st hinge with counter sunk holes facing up. Position hinge approx. 5" from end. Attach to top framing of 6x3 raised bed with **3 - 3/4" Black Screws** per hinge. Pre-drill shallow hinge holes first with 1/8" drill bit to prevent wood from splitting. Do not over screw with cordless screw gun!





**5.** Complete attachment of 1st hinge by screwing **3 - 3/4**" **Black Screws** into the lid framing as shown above. Evenly space remaining hinges and attach as described previously.



**6.** To complete Trellis/Lid installation, lift lid up and position in an upright position. You will have to hold in this position until Trellis/Lid arms are installed so an assistant would be helpful.









Screw top of arm to Trellis/Lid panel with 1 - 2" screw.

**8.** At the bottom of arm, attach a **2" screw** to a 1" depth in previously marked location. Arm notch will rest on screw and prevent Trellis/Lid from closing.





9. Complete remaining Trellis/Lid Arm (C) as per Steps 7 & 8.



**10.** If required, locate **Rear Trellis Cleat (D)**. Center on 6x3 Raised Bed center framing and Trellis/Lid panel framing. Attach with **4 - 2" screws** slighly offset from the center. At the end of your gardening season, carefully remove screws from cleat and store to use again for the next year.





We value your feedback and would like to hear back from you on how well we are doing in the following areas:

- 1. Customer Service
- 2. On Time Shipping
- 3. Motor Freight Delivery
- 4. Quality of Materials
- 5. Assembly Manual
- 6. Overall Satisfaction.

Please email John and Pat Motley info@CedarShedandGardenKits.com

The materials contained in this Assembly Manual may be downloaded or copied provided that ALL copies retain the copyright and any other proprietary notices contained on the materials. No material may be modified, edited or taken out of context such that its use creates a false or misleading statement or impression as to the positions, statements or actions.